

ASSEMBLY INSTRUCTION

KIT

X2. BARRACUDA BRACKET
X2. ALLEN SCREW M6X35
X2. SPECIFIC THICKNESS H.7MM

FRONT INDICATORS BRACKET KIT TRIUMPH STREET TWIN '16

TT9112-16

WWW.BARRACUDAMOTO.COM

ASSEMBLY PROCEDURE:

1. UNSCREW THE ALLEN SCREW POSITIONED UNDER THE HEADLIGHT AS SHOWN.
2. ASSEMBLE THE BRACKET USING THE SUPPLIED M5X35 AND THE SPECIFIC THICKNESS AS ILLUSTRATED.
3. TIGHTEN EVERYTHING.

