

MOUNTING PROCEDURE

KIT SAVE CARTER
HONDA CB 1000 R

HN1101

WWW.BARRACUDAMOTO.COM

KIT

X2. PVC HEAD
X2. SAVE CARTER BASE
X1. SPACER
X2. SCREWS 12X90



RIGHT SIDE:
attach point to the chassis



LEFT SIDE:
attach point to the chassis. Use the thickness in kit

Right side

Left side



MOUNTING PROCEDURE

FIND THE FIXING POINT ON MOTORBIKE, USE SPECIFIC SPACER AND BOLTS LIKE DESCRIBED IN THE PICTURE SO TO FIND THE RIGHT DISTANCE OF CRASH-PAD FROM THE MOTORBIKE. FIX THE PVC HEAD AFTER FIXED AND LOCKED ALL THE KIT ONLY.