

ASSEMBLING INSTRUCTION

KIT

X1. CHAIN COVER

X3. M6X10 X3. TEFLON WASHER Ø6

CHAIN COVER KIT AFRICA TWIN '19

HA1119-19

WWW.BARRACUDAMOTO.COM

ASSEMBLING PROCEDURE:

- 1. REMOVE THE ORIGINAL CHAIN COVER.
- 2. MOUNT THE BARRACUDA CHAIN COVER TO THE SWINGARM AS THE ORIGINAL ONE USING THE SUPPLIED M6X10 AND THE TEFLON WASHE, AS ILLUSTRATED.
- 3. TIGHTEN EVERYTHING.

