MOUNTING PROCEDURE

KIT NUMBER PLATE MOTO GUZZI V7

MG7400

KIT

X2. SPECIFIC BRACKET

X2. NUMBER PLATE

X4. SCREW 5X10 "ROUND HEAD"

X4. WASHER Ø 5 LARGE X4. AUTOLOCK NUT

X4. AUTOLOCK NOT X4. TEFLON WASHER X2. SCREW 8X25 "ROUND HEAD"

X2. NUT Ø 8 X2. SQUARE STICKER

WWW.BARRACUDAMOTO.COM

MOUTING PROCEDURE:

- FIN THE POSITION OF THE NUMBER PLATE BRACKETS FINDING THE LOCKING POINTS LIKE MOUNTING SCHEME;
- APPLY THE SQUARE STICKERS LIKE ILLUSTRATED (BELOW PART)
- APPROACH THE KIT NUMBER PLATE AND FIND THE POSITION;
- LOCK THE SCREWS AND REPEAT THE OPERATION FOR ALL MOUNTING POINT OF BRACKET

