

ASSEMBLING INSTRUCTION**WINDSCREEN KIT
VITPILEN 701 '19****HV7300-19****KIT**

X1. WINDSCREEN
X1. LEFT/RIGHT BRACKET KIT
X4. M5X14
X2. M6X30 ROUND HEAD
X4. TEFLON WASHER Ø5
X4. LARGE WASHER Ø5
X4. RUBBER WASHER
X4. SELF-BLOCKING NUT Ø5

WWW.BARRACUDAMOTO.COM**ASSEMBLING PROCEDURE:**

1. REMOVE THE 2 ORIGINAL SCREWS FROM THE HEADLIGHT'S BRACKET.
2. MOUNT THE SPECIFIC BRACKETS USING THE SUPPLIED M6X30 ROUND HEAD AND WASHERS, AS ILLUSTRATED.
3. PLACE THE NEOPRENE SQUARE BEHIND THE DASHBOARD, IN ORDER TO AVOID DAMAGES CAUSED BY VIBRATIONS.
4. FIX THE BARRACUDA'S WINDSCREEN TO SPECIFIC BRACKETS USING THE SUPPLIED BOLTS, AS SHOWN.
5. TIGHTEN EVERYTHING.

