

## ASSEMBLING INSTRUCTION

### WINDSCREEN KIT DUCATI SCRAMBLER

DR8300C

#### KIT

- X1. WINDSCREEN
- X1. LEFT/RIGHT BRACKETS KIT
- X4. M5X16
- X4. TEFLON WASHER Ø5
- X4. RUBBER WASHER
- X4. LARGE WASHER Ø5
- X4. SELF-BLOCKING NUT
- X2. M6X20
- X2. MILLED NUT

[WWW.BARRACUDAMOTO.COM](http://WWW.BARRACUDAMOTO.COM)

#### ASSEMBLING PROCEDURE:

1. REMOVE THE ORIGINAL INDICATORS AND ASSEMBLE WITH THEM THE SPECIFIC BRACKETS USING THE SUPPLIED M6X20 AND THE MILLED NUT, AS ILLUSTRATED.
2. MOUNT THE WINDSCREEN TO THE SPECIFIC BRACKETS USING THE SUPPLIED BOLTS, AS SHOWN.
3. TIGHTEN EVERYTHING.

