

**MOUNTING PROCEDURE****KIT WINDSHIELD  
KAWASAKI Z-800 '13****KN8300-13**[WWW.BARRACUDAMOTO.COM](http://WWW.BARRACUDAMOTO.COM)**KIT**

X2. BRACKET (1 RIGHT SIDE + 1 LEFT SIDE)  
 X2. "L" STIRRUP  
 X4. "ROUND HEAD" SCREW 5X12  
 X4. TEFLON WASHER DIAMETER 5  
 X4. RUBBER WASHER  
 X4. STICKER SQUARE RUBBER  
 X4. SPECIAL BUSH  
 X2. SQUARE SHAPE SCREW 6X16  
 X2. BLIND NUT DIAMETER 6  
 X4. LARGE WASHER DIAMETER 6  
 X2. "ROUND HEAD" SCREW 8X40  
 X2. ALUMINIUM THICKNESS

- 1** MOUNT THE BRACKET TO THE WINDSHIELD:  
 PUT THE SPECIAL BUSH ON THE REAR PART OF  
 THE BRACKET, PUT THE RUBBER WASHER BE-  
 TWEEN THE PLEXIGLASS AND THE BRACKET,  
 SCREW THE WINDSHIELD WITH THE 5X12  
 USING THE TEFLON WASHER



- 2** REMOVE THE FIXING SCREWS FROM THE UPPER  
 STEERING PLATE, INSERT THE SQUARE SHAPE  
 SCREW INTO THE "L" STIRRUP ALREADY  
 MOUNTED AND PUT IT LIKE DESCRIBED IN THE  
 PICTURE USING THE ALUMINIUM THICKNESS  
 AND THE 8X40 SCREW



- 3** MOUNT THE WINDSHIELD/SCREEN WITH THE "L" STIRRUP ALREADY ON IT. USE THE LARGE WASHERS AND THE BLIND NUT LIKE SHOWN IN THE PICTURE. FIND THE IDEAL POSITION AND LOCK ALL THE SCREWS



REMOVE THE FRONT PANEL, REMOVE THE FIXING HEADLIGHT BLOTS AND TURN IT. UNLOCK THE FIXING SCREWS OF STEERING PLATE AND MOUNT LIKE PICTURES THE "L" STIRRUP THAT YOU FIND IN THE INCLUDED KIT; LOCK ALL. CLOSE AND BLOCK THE HEADLIGHT; PUT AGAIN THE FRONT PANEL. MOUNT THE BRACKET TO THE PLEXIGLASS USING THE SPECIAL BUSH, 5X12 SCREWS, RUBBER WASHERS TO PUT BETWEEN THE WINDSHIELD/SCREEN AND THE BRACKET. PUT THE TEFLON WASHERS BETWEEN THE HEAD OF SCREW AND THE WINDSHIELD/SCREEN. APPLY THE STICKER SQUARE RUBBER IN CORRISPONDANCE OF THE SPECIAL BUSH TO AVOID SCRATCHES ON THE HULL. MOUNT THE WINDSHIELD/SCREEN ON "L" STIRRUP (LOOK AT THE PICTURE); FIND THE IDEAL POSITION AND LOCK ALL.