

## ASSEMBLY INSTRUCTION

### WINDSCREEN KIT DUCATI 797

DN7300-19

#### KIT

- X1. WINDSCREEN TYPE 'CLASSIC'
- X1. BRACKET KIT RIGHT/LEFT
- X1. SPECIFIC THICKNESS H.21MM
- X2. M5X50
- X4. M5X14
- X4. RUBBER WASHER
- X4. TEFLON WASHER Ø5
- X4. LARGE WASHER Ø5
- X4. SELF-BLOCKING NUT

[WWW.BARRACUDAMOTO.COM](http://WWW.BARRACUDAMOTO.COM)

#### ASSEMBLY PROCEDURE:

1. UNSCREW THE STOCK SCREW FROM THE BACK OF THE DASHBOARD.
2. ASSEMBLE THE BARRACUDA BRACKET USING THE SUPPLIED M5X50 AND SPECIFIC THICKNESS, TAKING CARE TO PLACE THE RUBBER WASHER BETWEEN THE BRACKET AND THE WINDSCREEN AS SHOWN.
3. MOUNT THE WINDSCREEN TO THE BARRACUDA BRACKET, USING THE SUPPLIED ALLEN SCREW M5X16 AND THE WASHERS AS ILLUSTRATED.
4. REPEAT FOR BOTH SIDES OF THE WINDSCREEN.
5. TIGHTEN EVERYTHING.

