

ASSEMBLING INSTRUCTION

FOOTPEG KIT HONDA X-ADV '18

HX7123-18

KIT

- X1. FOOTPEG KIT
- X2. SPACER H12.5MM
- X4. SPACER H17MM
- X2. M8X80
- X4. M8X35
- X1. M8X40
- X4. WASHER Ø8
- X1. SELF-BLOCKING NUT Ø8

WWW.BARRACUDAMOTO.COM

ASSEMBLING PROCEDURE:

1. ASSEMBLE THE FOOTPEG TO THE BARRACUDA BRACKET USING THE SUPPLIED BOLTS, AS ILLUSTRATED.
2. MOUNT THE FOOTPEG KIT TO THE INDICATED HOLES USING THE SUPPLIED ALLEN SCREWS AND SPACERS, AS SHOWN.
3. TIGHTEN EVERYTHING.

