

**MOUNTING PROCEDURE**

KIT NUMBER PLATE  
YAMAHA XSR

**YS7400**

[WWW.BARRACUDAMOTO.COM](http://WWW.BARRACUDAMOTO.COM)

**KIT**

X4. SPECIFIC BRACKET  
X8. SCREW 5X10 "ROUND HEAD"  
X4. WASHER LARGE Ø 5  
X4. TEFLON WASHER  
X8. AUTOLOCK NUT  
X4. SCREW 6X14 "ROUND HEAD"  
X4. SQUARE STICKER

**MOUNTING PROCEDURE:**

- FIND POSITION TO THE KIT NUMBER PLATE FINDING THE FIXING POINT AS IN THE SCHEME;
- APPLY THE SQUARE STICKERS INTO THE SHOWN SQUARE (BELOW PART);
- APPROACH THE KIT NUMBER PLATE AND FIN THE CORRECT POSITION;
- LOCK THE SCREWS AND REPEAT THE OPERATION FOR ALL THE FIXING POINT OF BRACKET;

