

# **ASSEMBLY INSTRUCTION**

**KIT** 

X1. SPECIFIC CHAIN COVER X2. LARGE WASHER Ø6 X2. SCREW M6X14 (ROUND HEAD)

# CHAIN COVER KIT YAMAHA MT-09

# YMT9119

# WWW.BARRACUDAMOTO.COM

# **ASSEMBLY PROCEDURE:**

- 1. REMOVE ONLY THE (1) SCREW OF THE ORIGINAL CHAIN PROTECTOR.
- 2. IMPORTANT: DO NOT REMOVE THE ORIGINAL PLASTIC CHAIN PROTECTOR.
- 3. FIT THE BARRACUDA CHAIN COVER ON THE TOP OF THE ORIGINAL ONE (1).
- 4. USE THE M6X14 SCREW INTO THE POINT (1) HIGHLIGHTED ON THE FORK.
- 5. TIGHTEN EVERYTHING.

